

Year: 2001-2006	Model: Acura MDX	Maintenance Menu Details
------------------------	-------------------------	--------------------------

Maintenance Item	Service Description Details	Recommended service interval
A	Replace engine oil and oil filter. Replace engine oil drain plug washer. Top up under hood fluids. Inspect and reset tire pressures.	<i>Every 3,750 miles or up to 3 months.</i>
B	Replace engine oil and oil filter. Replace engine oil drain plug washer. Inspect all fluid levels and condition of fluids. Check front and rear brake pads, rotors and brake calipers. Perform front and rear brake caliper slide pin service. Check parking brake adjustment. Rotate tires and torque all lug nuts by hand. Inspect tie rod ends, steering gearbox and gearbox boots. Inspect suspension components. Inspect drive shaft boots. Inspect brake hoses and lines including VSA lines. Inspect exhaust system. Inspect fuel lines and connections.	<i>Every 7,500 miles or up to 6 months.</i>
C	All items listed in "B" service plus: Replace the rear differential fluid.	<i>Every 15,000 miles or up to 12 months.</i>
D	All items listed in "B" and "C" plus: Replace the air and cabin inlet filters, transmission fluid, and transfer case fluid.	<i>Every 30,000 miles or up to 24 months.</i>
Rotate Tires	Rotate tires, check and set tire pressures and hand torque all lug nuts by hand.	<i>Every 7,500 miles</i>
Air Filters	Replace engine air filter, replace cabin pollen (inlet) filter and inspect drive belt.	<i>Every 15,000-30,000 miles</i>
Alignment	Adjust front and rear toe angles to be within factory specifications.	<i>Once every 12 months or 12,000 miles</i>
Transmission Fluids	Replace automatic transmission fluid and transfer case fluid.	<i>Every 20,000-40,000 miles</i>
Rear Differential Fluid	Replace the rear differential fluid.	<i>Every 15,000 to 30,000 miles.</i>
Brake Fluid	Flush brake system and refill brake fluid.	<i>Every 3 Years</i>
Coolant	Replace engine coolant.	<i>Every 75,000 to 105,000 miles</i>
Spark Plugs	Replace the spark plugs.	<i>Every 105,000 miles</i>
Timing Belt and Water pump	Replace timing belt, timing belt auto-tensioner, drive belt(s) and water pump and perform coolant service.	<i>Every 105,000 miles or 7 years</i>
Valve Adjustment	Adjust valve clearance and replace valve cover gaskets.	<i>Every 150,000 miles or when needed</i>

Maintenance Minder Definitions:

Above 20%: Service not required*	15 % Oil Life Remaining: Indicates "Service Soon"	5 % Oil Life Remaining: Indicates "Service Due Now"
--	---	---

*Please note: Maintenance intervals for any Acura vehicle are based partly on **Acura Maintenance Minder System** prompts and should include consideration of missed services as well as vehicle maintenance, repair history, and driving conditions. **If Acura Maintenance Minder does not prompt for one year after last reset, engine oil and filter should be changed, fluid levels and tire pressures checked.** **Environmental disposal and additional shop fees may apply and are not included in the Maintenance Minder "estimate".**

Effective 3/10/14